

USB VoIP Phone Quick Guide



Introduction

This USB phone provides you more conveniences to make free call over the Internet from PC to PC anywhere as easy as using normal telephones. The phone is fully compatible with Skype and can be used as audio device with Yahoo Messenger, MSN Messenger, MS NetMeeting, Google Talk, net2phone and etc for voice communication.

Installation

STEP 1: Connect the USB connector of the USB phone to your computer's USB port. When connected to your computer, Windows will automatically detect the new device.

STEP 2: If you're not using Skype, please skip this Step.

Download Skype software and install it (www.skype.com). The version must be 1.0.0.106 or higher.

Run Skype and log in with Skype account. You have to create a Skype account if you're use Skype for first time.


After software startup, the green Skype icon will appear to the system tray. **If the icon is not shown as, you have to check your Internet connection.**



STEP 3: Installing the Phone Manager

Phone Manager is a tool that enables your USB phone to communicate with Skype. You have to install the Phone Manager to allow the USB phone to access Skype functionality.

During the Phone Manager Installation process, make sure to select “Allow this program to use Skype” and click OK.



STEP 4: Using the USB Phone with Skype


When the USB phone is connected to a powered on computer, the device will start to connect to the installed Phone Manager. When the Phone Manager is successfully connecting the phone to Skype, the Phone Manager icon in the system tray will be changed, indicating the device is ready for use.



Using the Phone

Call Skype user from contacts

- Press Contact List once to display contacts.
- Press ▲/▼ to select a contact.


Press  to call out. Only one contact is displayed at a time. You can press Contact List key again to switch between Skype Friend List, Outgoing Call List, Incoming Call list and Missed Call List. The top-right icon indicates the online status of the contact.

  Means online while




  Means offline.

Call Skype user from call list

- Go back to idle. Press Contact List key twice, to display the outgoing call list.
- Press ▲/▼ again to select a contact.




The icons display in call list

- Incoming call 
- Outgoing call 
- Missed call 

- Press  to call out.

Call Skype user by Speed-Dial


- Add a friend (for example: bbc456) to Contacts
- Assign Speed-Dial for it, example "11"
- Press  to call out.

Call to regular phone

■ Press "00" + "country number" + "phone number", then press .

Example: call someone in Beijing, China

- Country code: 86
- City Code: 10
- Number: 12345678



Please press 00861012345678, and then press .

(1) You can input "+" instead of "00".

(2) If you want to use this function, you should buy SkypeOut Credit from www.skype.com first.


Answer a call

When a call comes in, USB VoIP Phone will ring.

Press  to answer the call, or press  to refuse it.

Adjusting Receiver Volume


Press


 to adjust volume when talking.

Troubleshooting

Problem 1

I no longer can hear anything played from my original sound card.

Solution: Please execute the “Control Panel->Sound and Video ()->Audio”, set Sound Playback and Sound Recording’s preference device to your sound card. See below:



Keypad Overview

Up/Down

Moves up and down in contact list; and

Volume

Up/Down during conversation

Skype

Status/Call Hold

Dial/Answer

Skype Tab

'+'

Pressing for 2 seconds. Used for SkypeOut

Call List

Press to switch between Friend List, Outgoing Call list and Incoming Call list;

Mute On/Off during

Conversation

Backspace

Speakerphone On/Off

Hang up/ Clear all entered numbers

Numpads

0-9, *, #

